



- NOTES:
- 1 1/4" Ø holes in neoprene sheet must be drilled or punched so that neoprene sheet is not distorted at the time of installation.
 - For Td value see "TYPICAL CROSS SECTION" sheet for TYPE II joint.